

## Minimum Material Condition (MMC) EQUINOX LH LWR INBOARD HEADLIGHT TAB HAL P/N 25-10073

- 1. Using a metric scale or ruler, measure your lamp at the reference points given in the figure below.
- 2. If the broken mounting tab meets the Minimum Material Condition value(MIN), then your lamp can be repaired using this kit.
- 3. If the broken mounting tab does not meet the Minimum Material Condition value(MIN), then your lamp is not a candidate for this repair kit.
- 4. If your lamp's mounting tabs have been repaired previously by any method, then your lamp is not a candidate for this repair kit.

